

INSTALLATION GUIDE FOR EXISTING STAIRCASES



Apply masking tape to side of handrail and treads to help mark existing balusters center.



Use a level to mark existing balusters center at the top and the bottom.



To keep the handrail supported cut out and remove only 4 or 5 balusters at one time then replace them with the adjustable wrought iron.



Once existing balusters are removed mark the centers on masking tape.



With the help of your Allen key, loosen the base set screws (1) and remove the base from the baluster. Apply adhesive underneath the base before aligning with the existing hole on the tread. Run screw through the baluster base into tread. Once the baluster base is set, place the baluster shaft into base.



Apply adhesive on the flat surface of the baluster swivel top. Loosen the telescopic shaft set screw (1) with Allen key and extend baluster to reach underside of the handrail. Adjust swivel top to handrail angle and secure into position using two screws.



Once the baluster is installed, tighten and lock the baluster base, telescopic shaft and swivel top with the set screw. It is suggested to apply thread locking liquid on the set screws. Do not apply thread lock liquid on the swivel top until it is securely screwed into the handrail.

TOOLS AND HARDWARE REQUIRED

- Phillips screw driver
- Level
- Construction adhesive
- 3 Screws per baluster
- Hand saw
- Masking tape
- Allen key
- Thread locking liquid

4 DESIGNS TO CHOOSE FROM



- Colour/Finish: Satin Black
- Height Adjustment: 30-1/4" to 38"



- Colour/Finish: Satin Black
- Height Adjustment: 30-1/4" to 38"



• Height Adjustment: 30-1/4" to 38"



- Height Adjustment: 30-1/4" to 38"

DÉCOR IDEAS



